To optimize microbial recovery - Please say NO to swabs.

No combinations. DON'T combine Microbiology samples with any other testing.



CALL 570-271-6504 WITH QUESTIONS.

REMEMBER, MORE IS MORE. HELP US HELP YOUR PATIENTS BY SENDING MORE FLUID TO IMPROVE RECOVERY.



Sterile cup or tube

**UTM** 




A Swab is NOT an acceptable transport device for fluid sources.

Mycobacteria (AFB)/Smear;

Collect fluid aseptically. If large volume ( > 5 mL), that will reach the laboratory within 1 hr., send fluid in sterile container or sterile tube.

## **OPTIONS/NOTES:**

- a) Large VOL: Fluid in large volumes (pleural, abscess, etc.) may remain in the evacuation bottle for transport.
- b) Small VOL: Flush small volume fluid in syringes/ needles with 0.5 ml of NOT send needle or swab to laboratory.



eSwab liquid to submit. Do



For Anaerobes: Place fluid in Anaerobic Transport Medium (ATM).



Place fluid in Universal viral Transport Media (UTM) at a 1:1 ratio.

For Low Volume Specimens: Flush small volume fluid in syringes/needles with 0.5ml of UTM liquid to submit. Do NOT send needle or swab to laboratory.

Do NOT submit swab or needle for fluid specimens.





If you "fix" it, that will nix it.



If Cytology assessment is required, submit SEPARATE specimen in a sterile cup or tube with a SEPARATE Cytology request form.

Other separate specimens and STAT **Laboratory Procedures** Form:

Cell count and differential: EDTA (lavender);

## **Chemistry tests:**

Glucose, protein, etc): Plain sterile red-top tube;

**Crystal detection (write** in form's Misc. section): EDTA, plain sterile, or sodium heparin

(lavender, red, or green);

Lavender Red Green



dmw:rmm: 8/9/23 GML Fluid Guide.vsd

GEISINGER MEDICAL LABORATORIES